





POTPROTM 3 GALLON - GENERATIVE STEERING (STEP 6)

SHOT VOLUMES

*GMV x Shot % = Shot Volume i.e., 11355ml x 5% = 570ml

*Growing Medium Volume

PROCESS

CALCULATE & REPLENISH

Dryback %

Shot Volume %

25 ÷ 5 = 5*

*Replenish Irrigation Cycles

*Round to the nearest whole number

DRYBACK

2270 ml - 3410 ml (20-30%)

EXAMPLE 25% DRYBACK AND 5% IRRIGATION CYCLES

